



Assembly Instruction for Decorative Rail Sets "Hand Drawn Rail System" with wall brackets type 11770, 11772, 11870 and 11872

(A) Wall bracket assembly / installation:

Attach the mounting plate (3) to the wall using the wood screws (2) and plastic dowels (1).

Place the cover (4) onto the mounting plate and tighten the bracket (5) (if using an additional bracket extension refer to (E) first).

If any adjustment of the bracket is needed, loosen the recess screw (6) with the allen key (7), turn the bracket to the desired position and tighten the recess screw again.

(B) Installation of the rail:

Push the rail (with the flattened side up) onto the locking nut (8) of the bracket and tighten the screw (9) with the allen key (7).

This locks the rail in place.

(C) Finial / end cap assembly:

Slide the finial (10) onto the rail. Lock finials with recess screw (6) using the allen key (7). Finials and end caps without recess screw

can be locked by a slight turn using light pressure.

(D) Recess bracket installation:

Drill hole and insert the plastic dowel (1). Attach the bracket (11) with the wood screw (2) and the rail with the recess screw (12).

(E) Bracket extension:

Attach the bracket to the extension using the recess screw provided with the extension.

Note: although each installation screw includes a plastic dowel, we recommend mounting into studs. We accept no responsibility for damages caused by improper assembly / installation.